# **Installation Guide**

### Model 267 and 267MR Differential Pressure Transducers



ATAL BV Postbus 783, 1440 AT PURMEREND Tel: 0299 630 610 Fax: 0299 630 611 www.atal.nl / info@atal.nl

## Atal offers a complete line of HVAC Products

Model 264	For Static Duct and Flow Measurement
Model 265	Smaller Size 10 PSI Overpressure
Model 230	Wet/Wet Differential Pressure Measurement
Model 209	Rugged Low Cost Gauge Pressure Measurement from 0-5 to 0-1000 PSIG

# Table of Contents

1.0	GENERAL INFORMATION	1
2.0	MECHANICAL INSTALLATION	2
	2.1 Media Compatibility	2
	2.2 Environment	2
	2.3 Pressure Fittings	2
3.0	ELECTRICAL INSTALLATION	2
	3.1 Voltage Output Units	
	1/2"Conduit Opening, PG9, PG-13.5 Electrical Termination	2
	3.2 Voltage Output Units	
	9 Pin D-sub Connector Electrical Termination	3
	3.3 Current Output Units	
	1/2" Conduit Opening, PG9, PG-13.5 Electrical Termination	4
	3.4 Current Output Units	
	9 Pin D-sub Connector Electrical Termination	5
	3.5 4-20 mA Circuit Diagram	5
	3.6 EMC Certification	5
4.0	CALIBRATION	6
	4.1 Voltage Output Zero Adjustment	6
	4.2 Voltage Output Span Adjustment	6
	4.3 Current Output Zero Adjustment	7
	4.4 Current Output Span Adjustment	7
5.0	MODEL 267 OPTIONAL LCD DISPLAY	7
6.0	MODEL 267MR MULTI-RANGE OPERATION	8
7.0	MODEL 267 & 267MR PERFORMANCE SPECIFICATIONS	9

#### Atal Systems Model 267 and Model 267MR

#### 1.0 GENERAL INFORMATION

Every Model 267 and Model 267MR (Multi-Range) has been tested and calibrated before shipment. Specific performance specifications are listed on Page 9 of this Guide.

The Model 267 is single range only. The Model 267MR has field selectable range capability. The 267MR is factory calibrated for the highest pressure range. The range label on the cover of the unit indicates the factory-calibrated range. Should the 267MR be re-ranged in the field, other Multi-Range labels are included.

Atal Systems 267 and 267MR pressure transducers sense differential or gauge (static) pressure and convert this pressure difference to a proportional high level analog output for both unidirectional and bidirectional pressure ranges. Two output versions are offered: A configurable voltage output of 0 to 5 VDC or 0 to 10 VDC, and a current output of 4 to 20 mA.

Sections 1 through 4 and 7 through 9 of this Guide apply to both Models 267 and 267MR. Section 5 refers to the Model 267 only. Section 6 refers to the Model 267MR only.

### 2.0 MECHANICAL INSTALLATION

#### 2.1 Media Compatibility

Model 267 and 267MR transducers are designed to be used with air or nonconducting gases. Use with liquids or corrosive gases will damage the unit.

#### 2.2 Environment

The operating temperature limits of the 267 and 267MR are as follows:

Operating Temperature	0°F to +150°F (-18°C to +65°C)
Compensated Temperature Range	+40°F to +150°F (+5°C to +65°C)

#### 2.3 Pressure Fittings

The Model 267 and 267MR can be supplied with three different pressure fitting configurations:

- A. 3/16" O.D. Barbed Brass Pressure Fittings Typically installed with 1/4" push-on tubing
- B. 1/4"NPT Brass Pressure Fittings Typically installed with mating NPT male fitting.
- C. Static Pressure Probe Installed on the duct by drilling a 7/16" hole in the duct at the desired mounting location, inserting the pressure probe into the duct, and mounting the 267 onto the duct with the mounting tabs.

For the 3/16" O.D. and 1/4" NPTF pressure fittings, both the positive (high) pressure port and the reference (low) pressure port are located on the bottom of the unit, labeled "HIGH" and "LOW" respectively. For best results (shortest response times), 3/16" I.D. tubing is suggested for tubing lengths up to 100 feet long, 1/4" I.D. for tubing lengths up to 300 feet, and 3/8" I.D. for tubing lengths up to 900 feet.

The static pressure probe is the positive (high) pressure port located on the back of the unit. The reference (low) pressure port is located on the bottom of the unit and can be used for differential pressure measurements.

#### 3.0 ELECTRICAL INSTALLATION

Wiring is through a 1/2" conduit opening or factory installed PG-9, PG-13.5 or 9 pin D-sub connector. (See Section 3.2 for instructions on wiring the 9 pin D-sub connector.) Both current and voltage output units are reverse wiring protected.

3.1 Voltage Output Units - 1/2" Conduit Opening, PG9 or PG-13.5 Electrical Termination

Wiring terminations are identified on the circuit board below the terminal strip (see Section 3.1 for voltage output units or Section 3.3 for current units). To access the terminal strip, turn the screws on top of the case counter clockwise until the cover can be removed. The screws are captured and will be secured in the top of the case.



Diagram 1

The Model 267 and 267MR voltage output is a 3-wire circuit, with three terminals available for wiring (see Diagram 1). The -Excitation and -Output are commoned on the circuit (see Diagram 2). The excitation/output specifications are:

Excitation Output	
9 to 30 VAC / 11.5 to 42 VDC	0 to 5 VDC
12 to 30 VAC / 13 to 42 VDC	0 to 10 VDC

The 267MR has a field selectable 0 - 5 or 0 - 10 VDC output. (See Section 6.0 for switch settings to determine whether the voltage output is set to 0-5 or 0-10 VDC.) The 267 has either a 0-5 VDC or 0-10 VDC output, calibrated at the Factory.



+EXC Connected to positive terminal of DC or AC power supply

#### 3.2 Voltage Output Units - 9 pin D-sub Connector Electrical Termination

The Model 267 and 267MR voltage output is a 3-wire circuit, with three pins available for wiring (see Diagram 3). The voltage output pin designations are shown in Diagram 4:

Diagram 4

	E	lagram	
PIN 1 PIN 4 + OUTPUT +EXC	CONNECTION	9 pin D-sub Connector Electrical Termination	
	+EXCITATION	4	
	+OUTPUT	1	
PIN 8, 9	COMMON	8,9	
Diagram 3	<u>Excitatic</u> 9 to 30 VAC / 11. 12 to 30 VAC / 13	n <u>Output</u> 5 to 42 VDC 0 to 5 VDC to 42 VDC 0 to 10 VDC	

\*Pins 8 and 9 are internally commoned together, user can connect to either pin.

#### 3.3 Current Output Units - 1/2" Conduit Opening, PG9 or PG-13.5 Electrical Termination

The Model 267 and 267MR is a two-wire loop-powered 4 to 20mA current output unit (see Diagram 5). The current flows into +EXC. terminal and returns back to the power supply through the -EXC. terminal (see Diagram 6). The power supply must be a DC voltage source with a voltage range between 9 and 30 measured between terminal +EXC. and -EXC. The unit is calibrated with a 24VDC loop supply voltage and a 250 ohm load.



#### 3.4 Current Output Untis – 9 pin D-sub Connector Electrical Termination

The Model 267 and 267MR is a two-wire loop-powered 4 to 20mA current output unit (see Diagram 6). The current flows into +EXC. Pin 4 (+EXC) and returns back to the power supply through Pin 9 (-EXC) (see Diagram 7). The power supply must be a DC voltage source with a voltage range between 9 and 30 measured between Pin 4 and Pin 9 (-EXC). The unit is calibrated with a 24VDC loop supply voltage and a 250 ohm load. The current output 9 pin D-sub connector pin designations are shown in Diagram 8.



CONNECTION	9 pin D-sub Connector
+EXCITATION	4
-EXCITATION	9

Diagram 8

3.5 4-20 mA Circuit Diagram

Minimum Supply Voltage (VDC) = 9 + 0.02 x (resistance of receiver plus line) Maximum Supply Voltage (VDC) = 30 + 0.004 x (resistance of receiver plus line). If the current loop has a current limiter, the threshold should be adjusted to 35 mA minimum (see Diagram 9).





3.6 EMC Certification

This product complies with EN61326-1:2006 in accordance with EN61326-2-3:2006 to be used in Controlled EM Immunity and Class B Emission environment. Special cautions must be take to fully meet EU EMC compliance:

1. Shielded cable must be used, and the shield must be tied to earth ground (not power supply ground) on at least one end of the cable shield/drain wire. The shield must be maintained all the way from sensor to the power supply.

- 2. If unshielded cable is used, an earth grounded metal conduit fitting can be used to replace the shielded cable.
- 3. For a sensor with a metal body or enclosure, the body/enclosure must be grounded to earth. If a protective metal housing is used, the metal housing should be grounded to earth
- 4. If a protective plastic housing is used, the housing must be able to withstand at least 2 KV from the housing to earth ground, without damaging the circuit.

#### 4.0. CALIBRATION

The 267 and 267MR transducer is factory calibrated and should require no field adjustment. Generally, the mounting position will have a zero shift effect on ranges below 1"WC. Whenever possible, any zero and/or span offsets should be corrected by software adjustment in the user's control system. However, both zero and span adjustments are accessible under the cover of the unit, below and to the right of the terminal strip. The 267 and 267MR transducer is calibrated in the vertical position at the factory (mounting tabs vertical).

#### 4.1 Voltage Output Zero Adjustment

While monitoring the voltage between the positive output (+SIG) and common (GND), and with both pressure ports open to atmosphere, the zero may be adjusted by turning the zero adjustment screw. (See Diagram 1 for location of zero adjustment.) Factory settings are:

Unidirectional Pressu	re Ranges	Bidirectional Pressure Ranges		
Zero Adjustment	Output	Zero Adjustment	Output	
0.05 VDC (±25 mV)	0-5 VDC	2.5 VDC (±25 mV)	0-5 VDC	
0.05 VDC (±50 mV)	0-10 VDC	5 VDC (±50 mV)	0-10 VDC	

4.2 Voltage Output Span Adjustment (Complete the zero adjustment before setting span.)

Span or full scale output adjustments should only be performed by using an accurate pressure standard (electronic manometer, digital pressure gauge, etc.),

with at least comparable accuracy to the 267 or 267MR transducer (< $\pm$ 1% FS). With full range pressure applied to the high pressure port (reference port open to atmosphere), the span may be adjusted by turning the SPAN adjustment screw. (See Diagram 1 for location of SPAN adjustment.) Factory settings are:

Unidirectional Pressu	re Ranges	Bidirectional Pressure Ranges		
Span Adjustment	Output	Span Adjustment	Output	
5.0 VDC (±25 mV)	0-5 VDC	2.5 VDC (±25 mV)	0-5 VDC	
10 VDC (±50 mV)	0-10 VDC	5 VDC (±50 mV)	0-10 VDC	

Example 1: Unidirectional pressure range of 0 to 1"W.C. with 0 to 5 VDC output

Apply 1.00" W.C., adjust span to 5 VDC (±25 mv) Example 2: Bidirectional pressure range of ±5"W.C. with 0 to 5VDC output Apply 5.00" W.C., adjust span to 5 VDC (±25 mV)

#### 4.3 Current Output Zero Adjustment

While monitoring the current output, and with both pressure ports open to atmosphere, the zero may be adjusted by turning the zero adjustment screw. (See Diagram 3 for location of zero adjustment) Factory settings are:

Unidirectional Pressu	re Ranges	Bidirectional Pressu	ire Ranges
Zero Adjustment	Output	Zero Adjustment	Output
4mA (0.08 mA)	4-20 mA	12 mA (0.08 mA)	4-20 mA

#### 4.4 Current Output Span Adjustment

Span or full scale output adjustments should only be performed by using an accurate pressure standard (electronic manometer, digital pressure gauge, etc.) with at least comparable accuracy to the 267 or 267MR transducer ( $<\pm1\%$  FS). With full range pressure applied to the high pressure port (reference port open to atmosphere), the span may be adjusted by turning the SPAN adjustment screw. (See Diagram 1 for location of SPAN adjustment.) Factory settings are:

Unidirectional Pressure	e Ranges	<b>Bidirectional Pressur</b>	e Ranges
Span Adjustment	Output	Span Adjustment	Output
20mA (0.08 mA)	4-20 mA	20 mA (0.08 mA)	4-20 mA

Example 1: Unidirectional pressure range of 0 to 1"W.C. with 4 to 20 mA output Apply 1.00"W.C., adjust span to 20 mA (±0.08mA) Example 2: Bidirectional pressure range of 5"W.C. with 4 to 20 mA output

Apply 5.00"W.C., adjust span to 20 mA (±0.08 mA)

#### 5.0 MODEL 267 OPTIONAL LCD DISPLAY

The Model 267 is available with an optional 3 1/2 digit LCD display. The LCD display is adjusted at the factory prior to shipment. The LCD is connected to the zero and span adjustment potentiometers. Therefore, adjustment of the zero and span according to Section 4 adjusts the LCD display.

#### 6.0 MULTI-RANGE OPERATION - MODEL 267MR ONLY

The 267MR is re-rangeable by accessing the switches located internal to the transducer housing. To access the "Dip" switches, remove the screws on the top of the case and lift off the cover. The "Dip" switches are located on the electronics board as shown in Diagrams 1 and 5. The voltage output version has 5 switches. The current version has 4. The location of these switches, "on" (up position) or "off" (down position), determine what range has been selected. See Table 1 or 2 below for switch positions for in.WC or Pascals.

Multi-Range units are factory set to the highest range. As an example, an MR2 range is factory set to 0 to 1"W.C.

If it is a 0-5 VDC output, the switches are set:



To change the range to 0 to .25"W.C. with a 0-10 VDC output, change the switches to:



If the 267MR Range is re-configured from the factory calibration, place the correct range label (enclosed) on the cover label, over the area indicating the factory default range.

Notes: Voltage output is set based upon ordering code. See switch settings below to confirm voltage output.

MR1	MR2	MR3	MR4	SWITCH	SWITC	SWITCH
RANGE	RANGE	RANGE	RANGE	SETTINGS	SETTINGS	SETTINGS
				0-5V	0-10V	4-20MA
				OUTPUT	OUTPUT	OUTPUT
	Factory [	Default Setti	ng	ON	ON	ION
0–0.1″	0–1″	0–5″	0–30″			
	05"	0-2.5"	0-15″			
				12345	12345	1234
				ON	ON	ON
	0 25"	0 1 25"	0 7 5"	Ĭ₽ <b>₽</b> ₽₽₽		ζ ¶ ₽ ₽ ₽
	025	0-1.25	0-7.5	1 2 3 4 5	1 2 3 4 5	1 2 3 4
±0.05″	±.5″	±2.5″	±15″			loğo
				12343	• 1 2 3 4 3	1234
				ON	ON	ON
	+ 25	+1 25"	+7.5″			
	29	_1.25	_/.5	1 2 3 4 5	12345	1234
				·····		······
	±.125″	±.625″	±3.75″			
				1 2 3 4 5	■ 1 Z 3 4 5	1 2 3 4

#### TABLE-1 RANGE SWITCHING INSTRUCTIONS FOR IN.WC



The 4-20 mA current version has only 4 switches.

#### 7.0 MODEL 267 & 267MR PERFORMANCE SPECIFICATIONS

Accuracy RSS <sup>*</sup> (at constant temperature.)	±1.0% FS
Non-Linearity, BFSL	±0.98% FS
Hysteresis	0.2% FS
Non-Repeatability	0.1% FS
*RSS of Non-Linearity, Non-Repeatability and	d Hysteresis.
Thermal Effects	
Compensated Range °F(°C)	+40 to +150 (+5 to +65)
Zero/Span Shift %FS/°F(°C)	0.033 (0.06)
Maximum Line Pressure	10 psi
Overpressure	10 psi in positive or negative
direction	
Warm-up Shift	±0.1% FS total
Position Effects	
(Unit is factory calibrated at 0g effect in the	vertical position)
Range	Zero Offset (%FS/G)
0 to .1″WC	2.1
0 to 1″WC	.22
0 to 5″WC	.14